BIDRIDGE QUICK REFERENCE

Flooring Designer

Floor layouts, seam plans, cove templates, cut and order lists

GET STARTED

1. Under What floor are you laying? pick a sample, or Start blank
2. Pick Room and tap the corners; tap the first corner to close
3. Tap the room to pick the product, pattern, base or flash cove

MAIN TOOLS

Room	Tap the room corners, or drag a rectangle
Doorway	Tap a wall where the door is; it gets a transition
Cabinets	Tap near a wall; the floor stops at the cabinet
Measure	Measures between two points; not saved or printed
Dimension	Adds a dimension that prints on the drawing set
Preview pages	Shows the full-size flash cove corner templates

KEYBOARD SHORTCUTS

Ctrl+Z	Undo (Cmd+Z on a Mac)
Ctrl+Y	Redo
Enter	Use the typed length, or finish
Tab or @	Type the angle after the length
Shift (hold)	Keep the line at 0, 45 or 90 deg
Esc	Cancel the drawing, then the tool
Delete	Delete what is selected
?	Open the shortcuts panel

WHAT GOES TO BIDRIDGE

- Each room: floor type, area and product to order
- Seams, heat weld, flash cove and wall base, with corners
- Transitions, VCT finish, pattern layout and extra cuts
- Client, site address, notes, Selections (FL1, FL2...)
- Files: drawing set, corner templates, cut and order lists

WHAT IT PRINTS

Drawing set and corner templates (PDF), order list and cut & seam list CSV, plan SVG

BEFORE YOU PRINT

- Print templates at actual size. Check the 1 in. square and 100 mm bar.
- Prices are starting prices only. Set yours under Products & prices.