BIDRIDGE QUICK REFERENCE

Roofing & Siding Designer

Roof plans, metal panel cut lists, trims, wall elevations and siding

GET STARTED

1. Under What are you roofing? pick a sample, or Start blank
2. Roof: pick Section and drag a rectangle; sections that touch join
3. Siding: tap Siding at the top, then a wall's tab

MAIN TOOLS

Section, Dormer	Roof: drag a rectangle; tap a plane for a dormer
Chimney, Skylight, Vent	Roof: tap the plane where it sits; drag to move
Window, Door, Fixture	Siding: tap the wall; fixtures get a block
Split, Area	Siding: new sections, wainscot or accent areas
Measure	Measures between two points; not saved or printed
Dimension	Adds a dimension that prints on the drawing set

KEYBOARD SHORTCUTS

Ctrl+Z	Undo (Cmd+Z on a Mac)
Ctrl+Y	Redo
Esc	Cancel the drawing, then the tool
Delete	Delete what is selected
?	Open the shortcuts panel

WHAT GOES TO BIDRIDGE

- Each roof section: area, pitch, layers and every edge
- Exact ice barrier, metal trim and snow guard feet
- Pipe boots, vents, kick-outs, chimneys, roof furring
- Each wall section: siding type, openings, corners, trim
- Mounting blocks; soffit, fascia, gutters, downspouts

WHAT IT PRINTS

Drawing set (PDF): roof plan, panels, elevations, a sheet per wall, trims; cut list and buy list CSV, plan SVG

BEFORE YOU PRINT

- Panel presets are catalog starting points. Confirm with your supplier.
- Smart trim follows the siding. Override it on a section, opening or line.